

FIG. 1

FIG. 2A




FIG. 2A




FIG. 2A




FIG. 2B




FIG. 2C





FIG. 3






FIG. 4B




FIG. 5




FIG. 6A



FIG. 6B




FIG. 6B





FIG. 7



104001-15612000

Custom - C:\NETMANAG\TCPIP.CFG		▼	▲												
File	Interface	Setup	Services	Disconnect	Help	▲	▼								
Interface: PPPO - COM1, 57600 baud															
Dial: 3826245															
IP Address: 198.137.231.20															
Subnet Mask: 255.255.255.0															
Host Name: boutell															
Domain Name:															
<table border="1"><thead><tr><th>NAME</th><th>TYPE</th><th>IP</th><th>DOMAIN</th></tr></thead><tbody><tr><td>PPPO</td><td>PPP</td><td>198.137.231.20</td><td></td></tr></tbody></table>								NAME	TYPE	IP	DOMAIN	PPPO	PPP	198.137.231.20	
NAME	TYPE	IP	DOMAIN												
PPPO	PPP	198.137.231.20													

815

Custom - C:\NETMANAG\TCPIP.CFG		▼	▲		
Stop	Save	Print	Copy	Clear	Close
login: boutell boutell Password: *****					
←					→

FIG. 8B




FIG. 9




FIG. 10




FIG. 11




FIG. 12

FIG. 13






FIG. 13





FROM CLIENT  
TO SERVER

FIG. 14



FROM SERVER  
TO CLIENT

FIG. 14